ZURURU. H98



ZURURU.COM

1 Installation of FitCloudPro app

Option 1

1. Use your smartphone to visit the website: ZURURU.COM/START

Open the link to install the FitCloudPro App on your smartphone.



Option 2

Download "FitCloudPro" from the App Store or Google Play and install it on your smartphone. **FitCloudPro** is only compatible with smartphones and requires the iOS 8.0 or above, or Android 4.4 or above operating system to run smoothly.

 Once the fitness tracker is successfully paired with the FitCloudPro app, the date and time will be automatically updated.

 Alternatively, you can manually set the date and time by accessing "Settings" (Function interface > settings > Date/Time) on the fitness tracker.

(2) Charging

Charge the fitness tracker before using it. It takes around 1-2 hours to fully charge the fitness tracker, and a full charge will provide working time for 5-7 days under normal conditions.

When charging, ensure that the magnetic connector of the charging cable is aligned with the charging contact area on the fitness tracker. You can charge it using any of the following methods:

- · Any phone or tablet power adapter
- · USB port on PC or power bank
- · Wall charger or power strip with USB port

③ Pairing

1. Enable Bluetooth on your smartphone.

 Open the FitCloudPro app. During the first launch after installation, the app will display a permission request, please allow ALL accesses for the app.
Sign up and login to the app, enter your personal information.

 Tap "+ Bind Device", and select your H98 to connect.

Warm Tips

1. If the FitCloudPro app is unable to find your H98 during device connection, you can try to reconnect Bluetooth and re-scan. If multiple H98 are detected, please select the H39 based on the MAC address of your device. You can view the MAC address under "Device Information" by sliding down the main interface and tapping on the (i) icon.



2. After successfully connecting with the app, the Bluetooth symbol will change from ∞ to ∞ .

3. One fitness tracker can be connected with a smartphone only at a time, make sure your fitness tracker is under unbind status before pairing.



(4) Appearance

 To operate, slide up, down, left, or right, and tap to select

 To turn the fitness tracker on or off. long-press the side hutton

Main Interface Style:

In the app, go to Device > Dial library, where you can select your preferred style for the main interface. Long-pressing the screen on the fitness tracker can switch between styles.

(5) Function Introduction

1 Interfaces

2 Function Interface

Slide left to enter the function interface, where you can slide up and down and tap to select the desired function. Available functions here include Data, Sleep, Workout, HR, SpO2, Female, Music, Messages, Stopwatch, Find Phone and Settings.

3. Data - Step Counting, Calories Burned and Distance

To check your step count, calories burned, and distance for the day, slide right once on the main interface to enter the "Data" interface. You can set your daily target goals in the app under Me > Exercise Goal

4. Heart Rate Tracking

To access the "HR" interface, slide right twice on the main interface. Wait for about 40 seconds for your heart rate reading to appear. To view the average heart rate over a set period of time, slide up on the HR interface.

Warm Tips

 Make sure the sensor on the underside of the device is always in direct contact with your skin of wrist, your fitness tracker should lay flat about one finger's width away from your wrist bone.

 You can enable the continuous heart rate monitoring feature in the app under Device > Automatic Health Monitor. This feature measures health data at intervals over a set period of time.

 \bullet The heart rate tracking results can be viewed in the app by going to Home > Heart Rate.

5. Sleep Monitoring

The fitness tracker automatically analyzes your sleep quality with deep sleep, light sleep, sleep duration, awake time, fall asleep and woke up time. The tracking result can be viewed in the app: Home > Last Night Sleep.

6. Sport Mode

a). Slide left on the main interface to access the function interface, and select "Workout" to enter Sport mode. From there, slide up or down and tap to choose from 7 activities, including Yoga, Elliptical, Running, Cycling, Basketball, Walking and Climbing. The data page will display real-time information on duration, BPM, Steps, Kcal and Km.

b). To exit Sport mode, slide left and tap the End icon. After syncing, you can review your tracking results in the app by going to Home > Sport (tap the running man icon at the top left corner).

7. SpO2 Tracking

Tap and select "SpO2" in the function interface, wait about 40 seconds for measuring and SpO2 reading to appear.

Warm Tips

 Continuous Sp02 monitoring feature can be enabled in the app (Device > Automatic Health Monitor), this feature measures the health data at intervals over a set period of time.

• The SpO2 tracking result can be viewed in the app: Home > Oxygen.

8. Female

This function is only available for female users. Tracking your menstrual cycle can help you recognize any recurring irregularities and identify patterns. To enable this feature, go to Me > Women's Health > Women's Health in the app. Tap and select "Female" in the function interface on the fitness tracker to check the status.

9. Music Control

After connecting with the app, select "Music" from the function interface to control the music app that's already installed on your smartphone.

10. Messages

When your phone receives a new message, your fitness tracker will vibrate to notify you. To enable message notifications, go to Device > Push Notifications in the app (the app must be running in the background of your smartphone).

11. Call Alert

When call alert is enabled in the app and there is an incoming call, the fitness tracker will vibrate, you can reject the call directly from your fitness tracker. To enable this feature, go to Device > Push Notifications > Call Alert in the app.

12. Stopwatch

Select "Stopwatch" from the function interface to access the stopwatch feature. Tap the right icon to start and pause the stopwatch, and tap the left icon to reset it.

13. Find Phone

To locate your phone, select "Find Phone" from the function interface. This will cause your connected phone to ring and vibrate (note that the app must be running in the background of your smartphone).

14. Alarm Setting

You can set up to 5 alarms per day. When an alarm is triggered, your fitness tracker will vibrate silently. To set alarms, go to Device > Alarms > "+" in the app.

15. Activity Reminder

Your fitness tracker will vibrate to remind you if you have been inactive for 1 hour. To enable this feature and adjust the alert time period, go to Device > Activity Reminder in the app.

16. Drink Reminder

Your fitness tracker will vibrate to remind you to drink water at set intervals. To enable this feature and adjust the reminder interval time, go to Device > Drink Reminder in the app.

17. Shake Photograph

To take a photo remotely using your fitness tracker, first open the app and select Device > Shake Photograph. Position your phone in the desired location for taking a photo, then shake your fitness tracker to capture the shot.

18. Waterproof

The fitness tracker is equipped with IP68 waterproof rating, allowing you to wear it during workouts, rain, or while swimming.

19. Power Saving Mode

Power Saving Mode can be enabled in "Battery" (Function interface> Settings > Battery) on the fitness tracker (Please note: When the fitness tracker enters power-saving mode, it will automatically disconnect from Bluetooth).

Kindly Note

If you still can't find what you're looking for, Please visit our help center: H98.ZURURU.COM or email us: **info**@zururu.com

24/7/365 Support Service.

Send us a message and we usually respond in a few hours.



HELP CENTER

VIDEO GUIDE, KNOWLEDGE BASE, TIPS, SUPPORT H98.ZURURU.COM

24/7/365 SUPPORT SERVICE